

Model	Amplifier Type	Selectable Timing for Ignition Timing	Retired Eclipse Veriflame Model Number. Call I.T.S. for the Correct Drop- in Replacement.
Purge	Ultraviolet (UV)	5 or 10 Sec	VF560222AA
		10 or 15 Sec	VF560522AA
	Flame Rectification (FR)	5 or 10 Sec	VF560223AA
		10 or 15 Sec	VF560523AA
No Purge	Ultraviolet	5 or 10 Sec	VF560232AA
		10 or 15 Sec	VF560532AA
	Flame Rectification	5 or 10 Sec	VF560233AA
		10 or 15 Sec	VF560533AA
Modulation	Ultraviolet	5 or 10 Sec	VF560242AA
Accessories	Modulation Base (Required with Modulation-Type Burner Controls)		49602-40
	Discrete Ultraviolet Flame Scanner, Straight Design		49600-90
	Discrete Ultraviolet Flame Scanner, 90° Right-Angle Design		49600-91
	Discrete Ultraviolet Flame Scanner, Self-Check		49602-91
	10' Cable Required for UV Self- Check Flame Scanner		49602-91-7
	Flame Rod, 12-Inch with 1/2-Inch NPT Connection		